

1957 Ford Fairlane Gauge Panel installation instructions.

Included mounting hardware:

Two 1/8" Z-Step Brackets

Two 1" Z-Step Brackets

Four 10-32 x 3/4" Socket Set Screws

Four 10-32 Nuts

- 1) The stock dash will need to be cut to allow the aluminum gauge panel to fit properly. (see the image below for an approximate cut path).
- 2) Insert the four 10-32 set screws into the back of the aluminum gauge panel.
- 3) Secure the aluminum panel to the stock bezel using the 1" Z-brackets & nuts on the bottom and the 1/8" Z-brackets & nuts on the top.
- 4) Install the gauges & LED lights into the gauge panel.

