

1960-61 GMC Truck Dash Insert installation instructions.

Included mounting hardware:

Eight 10-32 x 3/4" Socket Set Screws

Eight 1/4" Z-Shaped Brackets

Eight 10-32 Nuts

- 1) The stock instrument panel will need to be cut to allow the aluminum dash insert to fit properly.
- 2) Insert the Eight 10-32 studs into the back of the aluminum dash insert.
- 3) Secure the aluminum dash insert to your stock bezel using the Eight Z-shaped brackets, 10-32 studs, & nuts.
- 4) Install the gauges using hardware provided by the gauge manufacturer.
- 5) Install the LED lights.
- 6) Pre-wire the gauges, if you purchased a gauge wiring harness.
- 7) Install the assembled panel into your vehicle.

